



PERFORMANCE BEYOND LIMITS

3W INTERNATIONAL ECU UPDATE MANUAL




ATTENTION: Ensure a safe power-supply. A power loss during update may cause a crashed software copy.



1 Connect the **PowerBox** to your computer USB interface.

2 Open the ECU Motor Control software and select **Update**.



The following window appears:




Click **OK** to continue.

3 Click the **PowerBox Terminal** button located to your computer desktop.



The following window appears:



Click **Continue**.



The terminal program will identify the **ECU**.


ATTENTION: Ensure a safe power-supply. A power loss during update may cause a crashed software copy.



4 Online update or Select file.

By choosing „Online Update“ your computer must be connected to the internet.

By choosing „Select file“ the following window appears:



Select the **ECU-Typ_A.pbs** file and click **Open**.

5 Wait for the following window to appear and click **Update now**.



Please wait until the software update is finished. The message **Complete!** will appear.

The Update is now complete. Disconnect the USB connection and close the software.



CONTACT

3W International GmbH
Hollerstraße 12
61350 Bad Homburg
Germany

Phone: +49 (6172) 80 89 34-0

www.3w-international.com
info@3w-international.com

PERFORMANCE BEYOND LIMITS

