



STARTING PROCEDURE OF 3W HF ENGINES

Starting Procedure of HF Engines

1. TCU on, already set at factory
2. ECU on
3. Software open. Wait until cylinder temperature will reach :+65°C
4. Start engine now.
5. When engine is running, switch off TCU to prevent over heating.

CONTACT

3W International GmbH
Hollerstraße 12
61350 Bad Homburg
Germany

Phone: +49 (6172) 80 89 34-0

www.3w-international.com
info@3w-international.com

PERFORMANCE BEYOND LIMITS

